

# CLOCK FACES

## Supplies Needed:

- Plastic Clock

(Some of these clocks have plastic faces, while others have glass faces. You can find them at WalMart or at many craft stores. The clocks are under \$4 at WalMart with a glass face.)

- Cardstock or paper
- Scissors
- Double Sided Tape
- FREE Clock Face Printable ([Click Here For FREE Clock Faces](#))



## Instructions:

1. Remove the clear cover from the clock.

Plastic cover = gently pry it off with a thin knife.

Glass cover = These are usually screwed on. Just remove the little screws to remove.

2. Measure the diameter of the clock face. These clock face patterns are 6 1/2". You may need to resize your pattern, depending on your clock.

3. Resizing a pattern - Save the clock face to your hard drive and open it in a paint or editing program like Photoshop. Edit it to match the size of your clock and try printing it out on plain paper to be sure it is the correct size.

4. Once it is sized correctly, print the clock face on paper or cardstock. Cut out the face

and also cut out the small hole in the center (black circle indicates center of clock face) to accommodate the clock hands. (I use an ice pick to start the hole in the center, then make the hole larger by inserting a pen. Trim the excess paper.)

5. Now disassemble the clock face. Remove the hands from the center rod and lay them down in the order they were taken off. You'll need to know how to reassemble them when you've replaced the clock face.



6. Remove the paper clock face that came with the clock. If your clock face was permanently glued to the body of the clock, just use the double sided tape to cover the existing face with your new one.

7. Place double sided tape at the top, bottom and sides on the back of the new clock face and carefully position it to align the numbers properly.



8. Reset the hands and replace the plastic cover. You've got a brand new clock, ready to decorate your room!

